

easyWider blade spoiler fitting guide.

Thank you for purchasing this high quality vehicle spoiler.

Please read through all information provided within to ensure satisfactory fitment and long term durability.

The recommended installation method is detailed below.

**1. Preparation of the vehicle prior to bonding.**

- 1.1 Unpack the spoiler and keep in the warm and dry until fitting – it is recommended to fit the spoiler on a warm dry low humidity day for best adhesion.
- 1.2 Thoroughly Wash and degrease the area to be bonded to on the vehicle. A proprietary vehicle cleaner such as traffic film remover is ideal.
- 1.3 Once clean and dry, a secondary clean will be required using a clean, white lint-free cloth soaked in rubbing alcohol, making several passes, allow to dry.
- 1.4 The tape used adheres extremely well to both painted and unpainted substrates including plastics, however if you're bonding to bare unpainted textured plastic, please take extra care to ensure all remnants of trim shine detailing products have been thoroughly removed to ensure satisfactory adhesion.

**2. Fitting**

- 2.1 offer up the spoiler to the vehicle – the mounting tape is positioned to adhere to the specific location on the vehicle – usually the back edge of the roof / factory spoiler – once you are satisfied with the fitting location and the vehicle is fully prepared – peel the tape backing at one end of the spoiler approximately 2 inches (FIG!1) and allow this backing tape to still be accessible once the spoiler is offered up to the vehicle.
- 2.2 Hold the spoiler in place and ensure that all around you are happy with the location and fitment then slowly pull the rest of the tape film backing out from round the edges keeping the spoiler held in the correct position firmly pressed against the car, once all tape film backing has been removed apply pressure across the width of the spoiler side to side – the tape is pressure sensitive so pressure applied to the parts to be bonded is required for activation.

**NOTE Vauxhall Corsa D & E spoilers**

It is recommended to peel the first section of tape liner from the centre of the Corsa spoiler then align the centre of the spoiler to the car with an assistant holding it in place, then keeping the spoiler located slowly and carefully peel away the tape liner from behind the spoiler keeping it firmly pressed to the car as you do.

- 2.3 It is advisable to secure the ends of the spoiler to the car with masking or PVC tape to offer additional support whilst the tape adhesive reaches full curing strength – this can take up to 72 hours.



FIG 1.

All information provided within is intended as a reference aid to fitting the supplied vehicle spoiler. It is the sole responsibility of the end user to fully evaluate and determine suitability and cleanliness during fitment to the chosen vehicle, and that the person carrying out installation is competent to do so. It is advised to periodically check security of the spoiler attachment to the vehicle as part of vehicle maintenance routine. Therefore, no liability is accepted for loss, damage or injury that may arise as a result of using or during installation of this vehicle spoiler.