

IMPORTANT – PLEASE READ.

The attachment adhesives used on this product to secure it to the vehicle are best used in a warm and dry environment.

It is NOT recommended to attempt installation in cold or damp conditions – as a minimum the item and attachment surface should both be at room temperature ideally up to 30 degrees Celsius whilst fitting and for 24 hours thereafter.

If this is not achievable naturally this needs to be done artificially using supplementary heating such as fan or infrared heaters.

